




## USER GUIDE

THE TOMB PROFESSIONAL AND EXHIBITION TRAINING CAGE

Please Read this before using the products. Assembly by adults is required!

### COMPONENT LIST:

- . 1 The Tomb™ body with body bag;
- . 10 sets of pole with pole bag,
- . Stakes and tie down strings,
- . 1 repair kit.



**STEP 1:** Unroll and spread the The Tomb™ on the ground.

NOTE: Do not drop The Tomb™ bag or pole bag on its end. These actions may break the shock cord and/or damage the pole ends.

**STEP 2:** Assemble all the shock-corded poles. Make sure each pole section is firmly seated into the adjacent section.


**STEP 3:** The Tomb™ has 4 main cross arches and 6 side arches (3 on each side).

Install first 2 main cross arches starting with the front and then install first 2 side arches. With two persons, each one holds one end of the pole, gently flex the fiberglass pole into an upward position to form an arch, and insert the pole end into the pole sleeve at the base of The Tomb™. Clip plastic hooks around the frame poles starting from the top and go down both sides. Repeat this step with the middle and end section.

**Step 4:** Wrap the Velcro fasteners at each pole junction where poles meet to hold all poles together.

**Step 5:** Align The Tomb™ straight and tight, then stake down The Tomb™ by inserting and hammering stakes through stake loops on the floor edge. Then tie down the cage using ropes included in all directions.

**Step 6:** Take down The Tomb™ by reversing the steps above. Place stakes and poles into the pole bag. Fold The Tomb™ to the width of the carry bag and start a small tight roll and roll it from one end to the other.



Make sure The Tomb™ is clean and dry before storage. Recommend using the reusable and paintless to ensure the cleanness and long product life. Store The Tomb™ only in dry and good ventilation area.

## WARNINGS!

### Keep All Flame and Heat Sources Away from The Tomb™.


The Tomb™ is made with flame resistant fabric which meets CPAI-84 specifications. **IT IS NOT FIREPROOF.** The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the fabric may render the flame-resistant properties ineffective.

### Do NOT Leave Your Tomb™ Setup in Direct Sunlight Longer Than Necessary.

The sun's ultraviolet (UV) light degrades almost every fabric and material. While the netting has protection for (UV) light, the floor and doors, if left in sunlight for prolonged periods of time, will fade and weaken. UV Damage is not covered by the manufacture's warranty.



- DO NOT setup The Tomb™ near open fire;
- DO NOT use heating, lighting or cooking equipment with open flames in or near The Tomb™;
- DO NOT setup and/or leave The Tomb™ in high wind;
- DO NOT spray The Tomb™ with insecticide and other chemicals;
- DO NOT shoot towards the door and/or netting. Shoot towards the back target only;
- DO NOT shoot more than 250 FPS;
- DO NOT shoot each other in less than 20 feet distance.



### Important:

Exercise carefully when using electricity and lighting in and near The Tomb™. Always wear your MASK and other safety gears while playing. Put your barrel cover on before stepping out The Tomb™. Play safely and under adult supervision.

### Warranty:

The Tomb™ comes with 180 days limited warranty. The warranty covers quality, material defect as well as craftsmanship under normal intended use.

**Please be advised that the fiberglass pole may break during the use. This is NOT covered by warranty.**

The warranty does NOT cover wear and damage caused by improper use and operation, including but not limited to rough handling, abuse, tampering, unauthorized repair and maintained.

Warranty covers only one way freight to continental Europe. It is your responsibility to send the product back to us for repair or replacement;

Warranty service - always call or email us to report problem and get the instruction on how to get warranty service.